



www.socomi.com
www.pacificwoodlaminates.com

Pacific Wood Laminates, Inc.

We can do that.

Fax: (781) 998-6557

Phone: (541) 469-4177

Brookings, OR 97415

P.O. Box 820

885 Railroad Ave.



PAC *form*™
LINEAL

CONCRETE FORMS

It's True:

Our sanded or MDO-faced LVL edge forms save time, reduce waste, lower costs and remain uniformly flat and true after multiple pours.

Precision engineered
Laminated Veneer Lumber

Eliminates warping, shrinkage and waste

Remains consistently straight and true

Precut to precise lengths for easy installation

Sanded on two sides for smoother results

Can be sawn or drilled just like dimension
lumber

Lighter than competing LSL and OSB
products

Less edge swell than competing LSL and
OSB products

FSC Certification Available Upon Request



SCS - COC - 00636
The mark of responsible forestry
©1996 Forest Stewardship Council



CONCRETE FORMS

The following requirements and recommendations are essential to the performance and life of your PWL edge form.

Storage

All products should be stored out of the sun and rain or covered loosely to allow circulation without heat and/or moisture build up. Use stickers thick enough to keep products away from ground moisture, including snow. Keep products away from areas of standing water and heavy traffic. Refer to the PWL Technical Binder, Section 3, and/or visit www.apawood.org for additional information.

Recommended Release Agent

Pacific Wood Laminates recommends Noxcrete Chemically Active Form Release Agents. Refer to the PWL Technical Binder, Section 6, and/or visit www.nox-crete.com for additional information.

Stripping

Proper form stripping and handling procedures will prolong the life of the product. Wood wedges are recommended for stripping panels rather than metal tools. Forms should be lowered from the structure. Do not drop forms. For additional information refer to PWL Technical Binder Section 3, or www.apawood.org.

Form Cleaning

Soon after removal, forms should be inspected for wear, cleaned, repaired, and retreated with a chemically reactive release agent

before reuse. A hardwood wedge is preferred to hard wire brushes when scraping forms. Refer to the PWL Technical Binder, Section 3, or visit www.apawood.org for additional information.

Surface Repairs

See PWL Technical Binder, Section 3, or refer to www.apawood.org for more information.

Thickness: 1 1/4"

Length: 192"

Widths: 2 1/2" - 48"

Custom Sizes: Please Inquire



South Coast Lumber Co.

& Affiliates

GRNDF & KDDF Specialists

(541) 469-2136

www.socomi.com

885 Railroad Ave., P.O. Box 670
Brookings, Oregon 97415



Pacific Wood Laminates, Inc.

Engineered Wood Products

(541) 469-4177

www.pacificwoodlaminates.com

885 Railroad Ave., P.O. Box 820
Brookings, Oregon 97415



SCS-COC-00636

The mark of responsible forestry

©1996 Forest Stewardship Council

